



Still Image Capture

This unit is able to capture 4 still images.

These image files can be accessed via a web browser on the PC that is connected to the same network.

Launch the web browser on the PC to be connected to this unit, and enter the following text string in the address field to continuously record 4 still image files.

`http://[Camera IP]/cgi-bin/booth.cgi?0&4&[Interval]&photo&0`

[Interval] is used to set the interval for recording the still images in units of seconds. You can specify a value between 1 to 9 seconds for [Interval].

(Example: If the IP address of this unit is configured to 192.168.0.10 and 4 still images are captured in intervals of 5 seconds, enter the following text string in the address field:
`http://192.168.0.10/cgi-bin/booth.cgi?0&4&5&photo&0`)

To access a still image, launch the web browser on the PC to be connected to this unit, and enter the following text strings in the address field.

Image 1 : `http://[Camera IP]/photo1.jpg`

Image 2 : `http://[Camera IP]/photo2.jpg`

Image 3 : `http://[Camera IP]/photo3.jpg`

Image 4 : `http://[Camera IP]/photo4.jpg`