



メニュー設定値変更のお知らせ

■ VIDEO メニュー画面 (66、75 ページ)

項目	変更前	変更後
		
UP CONV. MODE (0405)	DV 入力信号または DV/DVCAM 記録テープ再生信号をアップコンバートして COMPONENT OUT 端子から出力する場合の映像モードを設定します	DV または HDV-SD50p 入力信号または DV/DVCAM または HDV-SD50p 記録テープ再生信号をアップコンバートして COMPONENT OUT 端子や HDMI OUT 端子から出力する場合の映像モードを設定します
TEST SIGNAL (0408)	TEST SIGNAL (0408)	TEST SIGNAL (0409)

項目	設定値	内容
MON.OUT ASPECT (0408)	<ul style="list-style-type: none"> ● FULL (00) LETTER (01) SIDE P. (02) (SIDE P. は 50Hz システムのみ)	HDMI OUT 端子および COMPONENT OUT 端子に出力される映像のアスペクト設定をします。お使いになるモニターのアスペクトに合わせて設定してください。 FULL : マルチフォーマットタイプの COMPONENT モニターや HDMI モニターなど、16:9 アスペクトのタイプを使用する場合。 LETTER : 4:3 アスペクトなど、16:9 以外のモニターに HDV 信号などの 16:9 映像を出力する場合。 SIDE P. : GR-PD1 の 576/50p モードアスペクト比 4:3 で記録されたテープを再生し、16:9 アスペクトのモニターに出力する場合 4:3 の画面はそのまま両端を黒くしたワイド映像で表示されます。 メモ 480i または 576i 映像を出力する場合は、このメニュー設定に関係なく固定のアスペクトになります。

■ DISPLAY メニュー画面 (78 ページ)



項目	設定値	内容
DISPLAY (0600)	<ul style="list-style-type: none"> OFF (00) ● ON (01) ON1 (02) ON2 (03) AUTO (04) 	映像出力端子に接続したモニターにステータス表示をオンスクリーンするかどうかを選択します。 OFF : オンスクリーン表示しません。映像のみ表示します。 ON : 常時オンスクリーン表示します。 ON1 : LINE OUT, Y/C OUT のみオンスクリーン表示します。 ON2 : CPN OUT, HDMI OUT のみオンスクリーン表示します。 AUTO : モード移行時、約 4 秒間オンスクリーン表示します。

Note on changes of setting value in Menu

TC/UB/CLOCK Menu screens (page 76)

Item	Before changes	After changes
DF BIT [50] (0502)	OFF (00) ☆ ON (01)	☆ OFF (00) ON (01)

VIDEO Menu screens (page 66,75)

Item	Before changes	After changes
		
UP CONV. MODE (0405)	Up-converts DV input signals or DV/DVCAM recorded tape playback signals, and sets the video mode for output from the COMPONENT OUT terminal.	Up-converts DV/ HDV-SD50p input signals or DV/DVCAM/ HDV-SD50p recorded tape playback signals, and sets the video mode for output from the COMPONENT OUT or HDMI OUT terminal.
TEST SIGNAL (0408)	TEST SIGNAL (0408)	TEST SIGNAL (0409)

Item	Setting	Description
MON.OUT ASPECT (0408)	☆ FULL(00) LETTER(01) SIDE P.(02) (SIDE P. is only for 50 Hz systems)	For setting the aspect ratio of the output from the HDMI OUT terminal and the COMPONENT OUT terminal. Set according to the aspect ratio of the monitor. FULL : Sets for aspect 16:9 monitors such as multiformat COMPONENT and HDMI monitors LETTER : Outputs aspect ratio 16:9 video such as HDV signals, to 4:3 and other non-16:9 monitors. SIDE P. : Shows 4:3 screen as widescreen video blackened on both sides when playing tapes recorded in aspect ratio 4:3 in 576/50p mode on the GR-PD1 on a 16:9 monitor. — Memo — Aspect ratio is fixed regardless of these settings when outputting 480i or 576i video.

DISPLAY Menu screens (page 78)

Item	Setting	Description
DISPLAY (0600)	OFF (00) ☆ ON (01) ON1 (02) ON2 (03) AUTO (04)	For turning on/off on-screen status display on the monitor connected to the VIDEO OUT terminal. OFF : No on-screen status display. Only video is displayed. ON : Always shows on-screen status display. ON1 : Shows on-screen status for only LINE OUT and Y/C OUT. ON2 : Shows on-screen status for only CPN OUT and HDMI OUT. AUTO : Shows on-screen status display for about 4 seconds during mode changes.