

### Precautions For Head Mounted Display

Always keep the product clean.

Because lenses such as half mirrors are coated, rubbing with a hard object may cause scratches.

If the product becomes dirty, follow the procedure below.

#### (1) Blow off the dust on the surface

Use a manual pump-type air blower or a soft-bristle brush for lenses to remove dust on the surface.

**Do not use a spray can type air duster. The gas may affect the performance of this product.**

As with glasses, you don't have to worry about fine small dust.

#### (2) Removing Contaminates

Use a clean, soft cloth or a lens cleaning cleaning paper lightly moistened with IPA (isopropyl alcohol) with a purity of 90% or higher.

When cleaning, wipe from the center to the outside with a light force. If you rub it too hard, it may be scratched.

### 本体のお手入れについて

- ・常に製品をきれいにしてください。
- ・ハーフミラー等のレンズはコーティング処理が施されていますので、硬いもので擦るとキズがつくことがあります。
- ・本製品が汚れた場合には、下記の手順を実施してください。

#### ① 表面の埃を吹き飛ばす

表面に付着した大きい埃は、手動ポンプタイプのエアブローアかレンズ用の柔らかい毛先のブラシを用いて取り除いてください。

**スプレー缶タイプのエアダスターは使用しないでください。ガスによって本機の性能に影響を与える可能性があります。**

メガネと同じように、細かい埃は注意する必要はありません。

#### ② 汚れを拭きとる

清潔なやわらかい布か、純度90%以上のIPA（イソプロピルアルコール）で軽く湿らせたレンズ清掃用クリーニング紙を用います。

清掃するときは中央から外側へ向かって軽い力で拭いてください。強くこするとキズがつくことがあります。